


Our Goal - Prevent Sewer Spills

- OC San relevant standard – 2.1 sewer spills per 100 miles.
- Collections' goal 0 spills



4

Л











Pressure Systems

- Pump stations 15
- Force mains 20 miles





10

Pump Station Maintenance

- Operational rounds
- Pump maintenance
- Wet well cleaning
- Controls/calibration
- Electrical maintenance
- Bypass contingency





11

11

Pump Station Resiliency

- Bypass pumping
 - Emergency response
 - Critical maintenance
 - Assessments
- Bypass pumping design
 - Unique to each station
 - Agile and quick assembly





12

Underground Line Locating

- State enforcement
- Damage prevention
- Other entity request
- Centralized system through state: Dig-Alert system
- Field locating and marking



13

13



Odor Control Chemicals

- Magnesium Hydroxide
 - Raises pH to keep HS⁻ in solution
- Ferrous Chloride (Ferric Salts)
 - Oxidize sulfide to sulfur
 - Precipitates sulfide as ferric sulfide
- Calcium Nitrate (Bioxide)
 - Naturally occurring bacteria biochemically oxidize dissolved sulfide in the presence of nitrate
- Sodium Hydroxide
 - Slough's off slime layer





15

15


Regional Odor Control Efforts

- Proactive outreach
- Investigate
- GIS tracking of "Hot Spots"
- Received AAEES award and patent for approach





16



Agency Assistance

- Assisted Costa Mesa Sanitary District (CMSD) and East Orange County Water District (EOCWD) with SSO response
- Assisted Irvine Ranch Water District (IRWD) with cleaning



18

